



## **HOW TO OPERATE AWARE GPS IN SLINGSBY FIREFLY**

1. Turn unit on by pressing power switch on top left corner of the unit. (Hold the button for approx 3 seconds).
2. Wait for the unit to start-up.
3. When the disclaimer screen is showing, touch the button on the bottom left of the screen which looks like a globe.
4. The map screen should appear.
5. Ensure the unit is centering on the aircraft (the button in the bottom right with the aircraft symbol should be orange – if not touch the button).
6. The unit will alert for approaching controlled airspace with bleeps and the box in the top right of the screen will flash.
7. The unit will alert on entry into controlled airspace with an alarm tone and the alert box will move toward the bottom of the screen and stop flashing.
8. Please switch the unit off at the end of the trip, by pressing the power button (top left of the unit) then tapping “Power off” button on the screen.

Happy Flying.